

WATCH — QUICK REFERENCE



HOW TO

Power On	Hold the power button for 2 seconds.
Power Off	Hold the power button for 4 seconds.
Select a Position	Tap any position on the grid.
Change Position	Press and hold the screen to return to the position grid.
Coach Mode	Double-press the power button. Coach Mode receives ALL plays, regardless of position.

TROUBLESHOOTING

Not receiving plays	Confirm the watch has the correct position selected.
Watch is stuck on a screen	Restart the watch: hold the power button to turn it off, then hold again to turn it back on.